



PENCIL SCRAPER

BLADE REPLACEMENT & GENERAL MAINTENANCE

Before scraping:

Inspect Cumberland scraper daily for visible signs of damage or defects. Make sure tool is free of oil or contaminants.

Clean the pipe of all abrasive substances. Scraping without cleaning the pipe could damage or dull blades very quickly. A damaged or dull blade will affect the peeling quality and could result in poor joint quality.

Make sure the blade is sharp and free of oil or contaminants. Clean with alcohol if necessary.

Scraper blades are in a fixed position. Blade part # **IQ001203** Screw part # **IQ001204**



Blades can be removed from tool using T-15 security screwdriver. Inspect blade for damages.



Blades can be rotated three additional locations before replacement.



Tighten screw until hand tight.

